



FS15-1

Desktop Rechargeable Fan


Shenzhen ZQ Dilligence Technology Co.,Ltd.

Add: Room2010, Angel Building, Bagua 4th Road, Yuanling Street, Futian District, Shenzhen, China.

Web: www.ProOne.hk


Company Introduction

ProOne, originated from the concept of Professional standard, dedicates to offer One superior user experience to customers. Focusing on providing innovative and excellent quality products, we attach great importance to customer demands. The idea of our design is to combine phone accessories to various lifestyles



Product Overview

Detachable by counterclockwise rotation



When the fan work, the indicator is blue LED L1-L3, L1 lights up at 1st gear, L1 and L2 lights up at 2nd gear, L1, L2 and L3 lights up at 3rd gear.

Short press the switch at the first time, the fan rotates into first gear; Short press the switch at the second time, the fan enters second gear; Short press the switch at the third time and the fan enters third gear. Press the switch at the fourth times to turn off the fan. When turning off the fan, if the rotation function is enabled, the rotation function will be turned off. Cycle in turn.

When the fan is working, short press the rotation switch to enable the shakehead function. Press the switch at the second time to disable the shake head function.

Long press the switch to turn on the night light; Long press again to turn off the night light.

Attention

- Children under the ages of 10 should use this product under the supervision of a guardian, and do not put fingers into the fan blades.
- In case of any accident, please seek medical care immediately.
- Do not disassemble or transform the product without authorization.
- Do not use the fan when it is soaked.
- Please avoid the impact of large distance vibration or falling from high altitude.
- Do not place the fan in damp or high temperature areas.
- When the fan is working, do not put your fingers or other objects into the protective net to avoid injury.
- When not in use, clean the oil and dust on the fan surface and put it in a dry and ventilated place to avoid squeezing.
- Do not disassemble, impact, squeeze, throw the battery into the fire or place it in a high temperature environment.
- When the battery is low, the indicator light flashes until it shuts off. Please timely plug in the charging cable and connect to the power supply to charge.
- If do not use it for a long time, charge it every three months to avoid battery damage.

Product Parameters

Brand	ProOne
Model	FS15-1
Power	10W
Gears	3
Weight	588g
Input	5V-2.0A
Motor type	Brushless motor
Battery capacity	2400 mAh
Size	294*187*150mm
Product color	White
Accessories	Type-C*1, Manual*1, Brochure*1, Thanks card*1

Operating Instruction

When charging, the red indicator lights up; When full, the green indicator lights up; Low power warning: Switch off after the gear indicator blinks for 5 times.

When the fan work, the indicator is blue LED L1-L3, L1 lights up at 1st gear, L1 and L2 lights up at 2nd gear, L1, L2 and L3 lights up at 3rd gear.

Short press the switch at the first time, the fan rotates into first gear; Short press the switch at the second time, the fan enters second gear; Short press the switch at the third time and the fan enters third gear. Press the switch at the fourth times to turn off the fan. When turning off the fan, if the rotation function is enabled, the rotation function will be turned off. Cycle in turn.

When the fan is working, short press the rotation switch to enable the shakehead function. Press the switch at the second time to disable the shake head function.

Long press the switch to turn on the night light; Long press again to turn off the night light.