



Shanghai Qiaopusi Smart Sci-Tech Development Co., Ltd.
 Адреса: кімната 103, 3-й корпус, No.320 Donglan Rd,
 Minhang
 Район, Шанхай, Китай
 Зроблено в КНР

ELECTRIC ROTARY SHAVER



User Manual

* For safety issue, the Product's battery status remains low during transporting.
 Please fully charge the Product before initial use!

IMPORTANT NOTES

Please read the following safety notes carefully and abide by all routine preventive measures for safety.

Warning

- This Product is not intended for use by young children or in firm persons with reduced physical, sensory or reasoning capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction by a responsible person concerning use of shaver to ensure that they can use it safely.
- This Product and its accessories are not toys. Close attention is necessary when used by or near children. Children should be supervised to ensure that they do not play with the product.
- Do not immerse this Product in water to charge, and do not charge it in a humid environment. Keep the shaver dry when using it.
 * The right symbol indicates that the shaver can not be cleaned under a running tap.
- The Product contains a built-in rechargeable battery. Do not drop it into fire and never charge, use or place it at the place where temperature is high.
- Do not drop or knock this Product. If this Product is damaged as a result of dropping or collision, do not use it again.




IMPORTANT NOTES

Notice

- After using each time, please put the protective cover on properly to prevent damage to the shaver mesh. To avoid any injury caused to the human body, do not use this Product if the mesh or the inner blade is damaged.
- The shaver blade is subject to certain service life. In order to maintain good effect, it is suggested to replace the blade on a regular basis.
- If this Product will be not used for a long time, please charge it at least once every six months.
- If this Product does not operate properly, please submit it to the seller or the authorized service center for inspection.
- This Product only applies to facial hair, so do not apply it to other parts of the body.
- Do not press this Product too hard on your lips or any other part of your face and do not directly contact your scar or damaged skin with the shaver blade net.

PROFILE OF PRODUCT



STEPS FOR USING

Slight skin irritation is normal when you first shave with the Product. Regular use of the shaver (at least 3 times a week) for 3 weeks is recommended for quick adaptation.

- Step 1**
 Remove the protective cover. Turn the shaver on by pressing safety lock and sliding switch up.
- Step 2**
 Shave against the direction of the beard growth on your skin using both straight and circular movements.
 * Dry face shaving experience will be better. It is suggested to use the Product before washing your face or after washing the face for a while.
- Step 3**
 Press power switch to turn off the electric shaver and put protective cover on to prevent the damage of the shaver blade.
 * Finish your look with the pop-up trimmer. It's ideal for maintaining your mustache and trimming your sideburns.



Notice:
 Improper use of the product may cause damage to the blade, please confirm whether the blade is in good condition before using. If damaged, stop using the shaver.

CHARGE YOUR SHAVER

- In case of power deficiency, the battery status indicator light twinkles to remind you of charging.
- Connect the Type-C charging cable to the shaver and the Adapter, then plug the adapter into the 100-240V AC power outlet.
 * 5W/1A Adapter shall be used.
- When charging, the battery status indicator light twinkles like breathing and reminds that the shaver is being charged.
- The shaver can be fully charged after 1 hour of charging, and the working status indicator light will be on.

Notice:
 If the shaver will not be used for a long time, please fully charge the shaver at least once every half a year.

PRODUCT PARAMETERS

Product name: Electric shaver
 Model: BlackStone/BlackStone-C
 Input: 5V \approx 1A
 Charging time: 1 hour




CLEANING AND MAINTENANCE

Notice:
 This shaver is non-waterproof, please do not rinse the body of the shaver with water.

- Before cleaning, be sure to turn off the shaver.
- Press shaver blade release switch with your fingers, open the blade assembly upward, and clean the beard collection part with a cleaning brush.
- Pull the shaver blade upward to remove it and then clean the shaving blade directly under a running tap.

Deep cleaning:
 1. Remove the cleaning rack as the knob direction of the rack.
 2. Detach the blade mesh, and clean the mesh with brush.
 3. After cleaning, the blade mesh and rack must be installed back in reverse sequence.



PRODUCT WARRANTY CARD

Name :	
Address :	
Tel. No. :	
Date of purchase : (dd / mm / yy)	
Store name :	
Warranty period :	

WARRANTY TERMS & CONDITIONS

- All quality-related defects on items sold directly by ENCHEN or ENCHEN's authorized resellers are covered by an extensive warranty, starting from the date of purchase.
- ENCHEN's limited warranty is restricted to the country of purchase. The limited warranty is void on items taken outside the country they were originally bought in or shipped to directly from an authorized online purchase.
- This warranty covers only original ENCHEN products. It is not applicable to normal wear and tear, or any defects arising from damage caused by misuse of this product.
- Warranty is for the primary product only nor transferable. Any free additional product(s) are not covered in this warranty.
- If the product fails regardless of usage in compliance with the user manual and other written precaution, replacement will be provided free of charge.
- To claim the warranty, contact the services team from the platform or store where you bought from.

✉ Email: export@enchen.cn

BATTERY DISPOSAL INSTRUCTION

- Please take the battery out from the appliance first before discarding it.
- Please make sure that the appliance is powered off before taking out the battery.
- The battery should be disposed safely.