



**Contents** [ [hide](#) ]

- [1 JISULIFE Ultra2 Portable Handheld Fan](#)
- [2 INTRODUCTION](#)
- [3 SPECIFICATIONS](#)
- [4 WHAT'S IN THE BOX](#)
- [5 FEATURES](#)
- [6 SETUP GUIDE](#)
- [7 CARE & MAINTENANCE](#)
- [8 TROUBLESHOOTING](#)
- [9 PROS & CONS](#)
- [10 WARRANTY](#)
- [11 FREQUENTLY ASKED QUESTIONS](#)
- [12 References](#)



**JISULIFE Ultra2 Portable Handheld Fan**



## INTRODUCTION

A high-performance portable fan with exceptional versatility and outdoor convenience is the JISULIFE Ultra2. This device, which costs **\$74.99**, has a 43,000 RPM turbo engine, up to 100 wind speed settings, and a 9000mAh rechargeable battery that can run for up to 25 hours between charges. This 5-in-1 device is a dependable travel, camping, beach, concert, or emergency companion because it can be used as a fan, 18W power bank, 4-level flashlight, air pump, and dust blower. The Ultra2 combines functionality and power in a small, fashionable package with a sturdy metal casing, USB-C quick charging, real-time digital display, and safety lock. The JISULIFE Ultra2 offers strong airflow, multipurpose tools, and peace of mind wherever you go, whether you're preparing for outdoor activities or dealing with the summer heat.

## SPECIFICATIONS

Brand	JISULIFE
Model	Ultra2
Price	\$74.99
Weight	Approx. 10.4 oz (295 g)
Dimensions	5.31" × 2.95" × 1.57"
Motor Speed	Up to 43,000 RPM
Speed Levels	1–100 adjustable + Storm Mode
Battery Capacity	9000mAh rechargeable Li-ion
Charging Interface	USB-C (Input/Output)
Charging Time	2.5 – 3.5 hours
Runtime	1.5 – 25 hours (depending on usage)
Flashlight	3 brightness levels + 1 flashing mode
Power Bank Output	18W Quick Charging
Shell Material	Metal
Blade Material	Aluminum (9 blades)
Noise Level	Approx. 65 dB
Control Method	Scroll Wheel / Touch
Reusability	Rechargeable
Usage Scenarios	Outdoor, travel, beach, camping, concerts
Cordless Operation	Yes

## WHAT'S IN THE BOX

- JISULIFE Ultra2 Handheld Fan
- USB-C Charging Cable
- 2 Magnetic Air Nozzles
- Removable Rear Mesh Cover
- User Manual

## FEATURES

- **Airflow Control:** Offers 100-speed levels for precise adjustment.
- **Motor Power:** Equipped with an ultra-strong 43,000 RPM motor for high-performance cooling.



- **Storm Mode:** Instantly boosts airflow for rapid relief in hot conditions.
- **Battery Capacity:** Built-in 9000mAh rechargeable battery for extended use.

# 9000mAh Large Battery

Up to 25 Hours of Runtime



- **Runtime:** Provides up to 25 hours of operation on a full charge.
- **Reverse Charging:** Works as an 18W power bank to charge other devices.

# 18W Reverse Fast Charging

Your Backup Power Bank



- **Charging Time:** Fast USB-C charging completes in about 2.5 to 3.5 hours.
- **Flashlight Function:** Features a 3-level LED light with an emergency SOS mode.

# A Good Helper for Outdoor Lighting

Lighting Number of levels  
Brightness (at 100cm)

Level 1

8502K color temperature, 35LUX

Level 2

8634K color temperature, 67LUX

Level 3

10195K color temperature, 82LUX




- **Digital Display:** Real-time screen shows wind speed and remaining battery.



- **Safety Guard:** Honeycomb mesh design prevents accidental contact with fan blades.
- **Lock Feature:** Safety switch avoids unintended power-on while in transit.
- **Easy Cleaning:** Rear mesh is detachable for quick blade cleaning.
- **Build Quality:** Strong metal casing ensures durability for outdoor use.
- **Multi-Use Nozzles:** Includes 2 magnetic tips for dust blowing or inflating items.
- **Portability:** Compact build is ideal for carrying during travel or camping.

# 5 IN 1 Handheld Fan



## SETUP GUIDE

- **Initial Unboxing:** Remove the unit from packaging and confirm all parts are present.
- **Charging:** Fully charge the battery using the USB-C input before first use.
- **Power On:** Rotate the main dial from “O” (off) to “-” (on) position.
- **Speed Adjustment:** Use the scroll wheel to fine-tune wind speed.
- **Storm Mode:** Press and hold the scroll wheel for 3 seconds to activate high-speed cooling.
- **Display Monitoring:** Check the screen to view current speed and battery level.
- **Flashlight Use:** Extend the flashlight section and tap to cycle through brightness levels.
- **Emergency Signal:** Hold the flashlight button to switch on SOS mode.
- **Nozzle Attachment:** Snap on the magnetic nozzles for cleaning or inflating tasks.
- **Device Charging:** Use the USB-C output port to charge your phone or gadgets.
- **Fan Locking:** Turn the dial back to “O” to safely shut off and lock the fan.
- **Cleaning Access:** Remove the rear mesh to access and clean the fan blades.
- **Storage Location:** Keep the device in a cool, dry area when not in use.

- **Battery Maintenance:** Recharge before storing it for long durations.



## CARE & MAINTENANCE

- **Turn Off First:** Always power down the fan before starting any cleaning.
- **Wipe Exterior:** Use a dry or slightly damp cloth to clean the outer body.
- **Dust Removal:** Use the included nozzles or a soft brush to clear debris.
- **Water Safety:** Avoid letting any moisture enter the charging or air vents.
- **Mesh Maintenance:** Detach and clean the rear mesh cover regularly to ensure airflow.
- **Avoid Submersion:** Never immerse the fan in water.
- **Port Care:** Keep USB-C charging ports clean and free from particles.
- **Battery Health:** Recharge at least once every 3 months during storage.
- **Heat Protection:** Do not expose the fan to high temperatures or direct sunlight.
- **Storage Tip:** Store in the original box to protect the unit from damage.
- **Lens Cleaning:** Wipe the flashlight lens gently using a microfiber cloth.
- **Cable Use:** Only use the original USB-C charging cable to prevent internal damage.

- **Internal Safety:** Do not attempt to disassemble any of the internal components.
- **Magnet Check:** Inspect magnetic nozzles for rust or wear regularly.
- **Control Test:** Ensure the dial and buttons function smoothly without sticking.



## TROUBLESHOOTING

Issue	Possible Cause	Solution
Fan won't turn on	Battery low or locked position	Recharge; set dial from "O" to "—"
Storm Mode not working	Short press or scroll wheel issue	Hold scroll wheel for 3 seconds
Flashlight won't work	Battery low or flashlight not extended	Recharge; ensure flashlight is properly pulled out
No wind from fan	Speed set to 0	Increase speed using scroll wheel

Issue	Possible Cause	Solution
USB output not charging	Cable issue or battery depleted	Try different USB-C cable; recharge fan
Fan makes loud noise	High speed or debris in blades	Reduce speed; clean blades
Buttons unresponsive	Internal lock enabled or software bug	Turn off and restart device
No digital display	Power off or screen fault	Recharge; check for damage
Air nozzle not working	Improper installation	Reattach nozzle and check airflow
Flashing light not active	Mode not toggled correctly	Long-press flashlight button again

## PROS & CONS

### Pros

- High-performance 100-speed fan with turbo motor
- Long battery life and fast USB-C charging
- Built-in flashlight and emergency functions
- Dual-use as power bank and dust blower
- Compact yet solid metal body

### Cons

- Louder than average handheld fans (~65 dB)
- Premium price point
- Slightly heavier than plastic models
- Advanced features may require learning curve
- Flashlight controls could be more intuitive

## WARRANTY

The JISULIFE Ultra2 includes a **1-year limited warranty**, covering manufacturing defects and internal malfunctions. The product is also eligible for **30-day returns** through most authorized retailers. Customer support is available via JISULIFE's official service channel.

- [support@jisulife.com](mailto:support@jisulife.com)

## FREQUENTLY ASKED QUESTIONS

What makes the JISULIFE Ultra2 fan different from regular handheld fans?

The JISULIFE Ultra2 offers 100 adjustable speeds, a powerful 43000 RPM motor, a 9000mAh battery, a flashlight, and acts as an 18W power bank.

How long can the JISULIFE Ultra2 Portable Fan operate on a full charge?

The fan provides up to 25 hours of usage depending on speed settings and flashlight usage.

Can the JISULIFE Ultra2 be used as a power bank?

The Ultra2 model supports 18W reverse quick charging, allowing it to charge other USB devices efficiently while on the go.

What kind of display does the JISULIFE Ultra2 have?

It features a digital screen that shows current wind speed and remaining battery life in real time.

What lighting modes are included in the JISULIFE Ultra2 fan?

The built-in 4-level flashlight includes 3 brightness levels and 1 flashing emergency mode, perfect for outdoor or emergency use.

How do I activate Storm Mode on the JISULIFE Ultra2?

Press and hold the speed scroll wheel for 3 seconds to enter Storm Mode (max wind 17m/s), then release to return to your set speed.

What accessories come with the JISULIFE Ultra2 fan?

It includes 2 magnetic air nozzles for dust removal or inflation tasks and a USB Type-C cable for charging.

## References

- [User Manual](#)

📄 B0F38H258L, JISULIFE, Ultra2 Portable Handheld Fan, user

📁 JISULIFE manual

---

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

**Search:**

e.g. whirlpool wrf535swhz

**Search**

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.